

取扱説明書

INSTRUCTION MANUAL

使用说明书

保証書付

要保管

CHOUOHC

THE MORPHO CARVER



※ご使用前には必ずこの取扱説明書をよくお読みになり、大切に保管してください。

目次

- 取扱説明書に関するご注意 p. 2
- 正しく安全にご使用いただくために p. 2~3
- 使用前のご注意 p. 4
- 使用中のご注意 p. 5
- 保守・点検のご注意 p. 6
- 各部の名称 p. 7~8
- 機能の説明 p. 9
- 充電方法 p. 9
- 操作方法 p. 10
- トリートメント手順 p. 11~12
- 製品仕様 p. 13
- リチウムイオン電池のリサイクルについて p. 13
- 保証規定 p. 14
- MEMO p. 44~46
- 保証書 裏表紙


取扱説明書に関するご注意


- この度は弊社商品をご購入いただきまして、誠にありがとうございます。
取扱説明書は本機器を安全にお使いいただくために必要です。本機器を人に貸したり、差し上げる時には必ずこの取扱説明書を一緒にお渡してください。
- この取扱説明書には保証書がついています。
「ご購入日・ご購入店舗」などの記入を必ず確かめ、大切に保管してください。


正しく安全にご使用いただくために

ご使用の前に必ず本紙をお読みにになり、正しくご使用ください。

お客様や他の人への危害や財産への損害を未然に防止するために、以下のような表示をしています。警告サインの表示と意味は次のようになっています。

 **危険** 「死亡や重傷を負うおそれ大きい内容」です。

 **警告** 「死亡や重傷を負うおそれがある内容」です。

 **注意** 「軽傷を負うことや、財産の損害※が発生するおそれがある内容」です。
※家屋・家財および家畜・ペットにかかわる拡大損害を示します。

■図記号



してはいけない「禁止」を示しています。
※図の中や近傍に具体的な内容が書かれています。



しなければならないことを示しています。



注意しなければならないことを示しています。

正しく安全にご使用いただくために

⚠ 警告

事故や体調不良などを防ぐために

- 次のような医用電子機器を装着している人は、本機器を使用しないでください。

医用電子機器の誤作動は、事故や体調不良の原因となります。

- ペースメーカーなどの体内植込型医用電子機器
- 人工心肺などの生命維持用電子機器
- 心電計や点滴器などの装着型の医用電子機器



禁止

- 以下の人は使用しないでください

- 心臓疾患・血圧異常時・悪性腫瘍
- 発熱を伴う疾患・感染症疾患・急性疾患
- 歯の治療中
- エイズなどの免疫性疾患による免疫力の低下、または免疫抑制剤を使用している人
- 血友病疾患・出血性疾患・糖尿病・顔面神経痛
- 知覚・痛覚異常のある人
- ケロイド体質・顔面黒皮症・光過敏症・色素異常
- ステロイドホルモン剤の長期使用や、肝機能障害で毛細血管拡張を起こしている人
- アレルギー体質・アトピー性皮膚炎・皮膚病・敏感肌または肌の弱い人
- てんかんの既往のある人・光の点滅で気分が悪くなる人
- 交通事故などによる頭部及び眼科的後遺症のある人
- 目の手術を行った人(レーシックの場合、医師にご相談の上ご使用ください)
- 妊娠中・生理中・授乳中
- 幼児・自分で意思表示のできない人
- 酒気帯び・二日酔いの人
- 眠気を誘う薬を服用中の人
- 疲労の激しい人・体調のすぐれない人
- 化学繊維でシミ・かぶれ等の肌トラブルのあった人
- 化粧品による皮膚炎を起こしている人・起こした人
- エステ等でケミカルピーリングをした直後の人
- 美容機器の使用後に肌トラブルのあった人



禁止

- 以下の部位には使用しないでください

- 指定された部位以外
- 心臓周辺・眼球及び上まぶた・唇や口の中など粘膜の部位
- 陰部・肛門・のどぼとけ周辺・耳
- 病的なシミ・ホクロ・ウィルス性のイボのある部位
- 過度の日焼けで肌がヒリヒリし、炎症を起こしている部位
- 傷口・湿疹・乾癬・ヘルペス・化膿したニキビ・吹き出物のある部位
- 痒みや火照り、物理的刺激などによる病的なシミのある部位
- 手術した部位
- 脱毛や剃毛処理をした直後の部位



禁止

※通院中の方は医師にご相談の上、ご使用ください。

使用前のご注意

⚠ 警告

- 他の美容機器とは同時に使用しないでください。
- 美容目的以外の使用や、破損・故障した状態で使用しないでください。本機器は美容専門のトリートメント機器です。治療目的など、用途以外に使用しないでください。
- LED光を覗いたり、直視をしないでください。
- 同じ部位への連続使用はしないでください。肌を傷つけたり、感染症・炎症・出血・色素沈着などのトラブルや症状悪化の恐れがあります。
- アルコール成分が含まれている美容液を使用しないでください。肌トラブルになる恐れがあります。
- ペットには使用しないでください。
- 引火性のものの近くで使用しないでください。
※シンナー・ベンジン・除光液・スプレーなど
- 専用ACアダプター・USBケーブル以外で使用しないでください。専用ACアダプター・USBケーブルを他の機器に接続しないでください。(火災・感電・故障の原因)
- ケーブルを傷めないでください。
※傷つける・無理に曲げる・引っ張る・ねじる・重い物を載せる・挟み込むなど(火災・感電・故障の原因)
- たこ足配線をしないでください。(発熱・火災の原因)



禁止



水場使用禁止



水ぬれ禁止



ぬれ手禁止



プラグを抜く

- 浴室や湿気の多い場所で使用・保管しないでください。
- 水のかかりやすい場所(洗面台の上など)に置かないでください。

- 水に浸けたり、かけたり、こぼしたりしないでください。(感電・火災・故障の原因)

- 濡れた手で触らないでください。(感電・けがの原因)

- ACアダプター・USBケーブルを抜き差しする時は、必ず先端のプラグを持って抜き差ししてください。ケーブルを持って抜き差ししないでください。
- ACアダプター・USBケーブルが傷んだり、コンセントへの差し込みがゆるい時は使用しないでください。



必ず守る

- 必ず家庭用コンセントで使用してください。
- ACアダプターやUSBケーブルは、根元まで確実に差し込んでください。
- 取扱説明書の内容を必ずお守りください。守らずに使用されると、何らかのトラブルが発生する恐れがあります。

使用中のご注意

⚠ 警告



プラグを抜く

- 次の場合は使用を中止し、電源を切り、ACアダプターをコンセントから抜いてください。
 - ・地震・雷
 - ・本体やACアダプター・USBケーブルからの発煙・異常発熱・異臭・変形



禁止

- 使用中、本機器が熱を帯びることがありますが、安全性に問題はありません。
- 本機器を金属や電化製品に接触させないでください。
※携帯電話・テレビなど
- 本機器を初めて使用される前は、必ずフル充電をしてください。
※充電を十分せずに使用されると、使用中で電源が切れる可能性があります。



必ず守る

- 使用の際は、必ず貴金属類や眼鏡・コンタクトレンズを外してください。
※貴金属類:ピアス・ネックレス・時計など
- 初めて使用する時や慣れるまでは、必ずレベル1から使用してください。
- ヘッドは強く押しつけず肌にあて、同一箇所へ3秒以上固定したままにしないでください。肌トラブルの原因になります。
- 目のまわりのトリートメントの際は目を閉じてご使用ください。
- 使用中に肌や身体に痛み、異常を感じたら直ちに使用を中止し、医師にご相談ください。

⚠ 注意

本体使用上のご注意 以下の項目をよく読んでご使用ください。

1

- 特別なトリートメントは週1回行ってください。
- 1週～2週目は週に2回お手入れしてください。その後の3週目からは肌の調子に合わせて週に1回程度お手入れしてください。
- 過度なお手入れはかえって肌によくありません。
- 毎日のトリートメントは毎日または2日に1回行ってください。
- 肌の調子に合わせてご使用ください。

2

- トリートメントは、クレンジングや洗顔を行い、化粧や皮脂等の汚れを落としたうえでご使用ください。

3

- 肌の状態は、体調によっても異なります。
- 肌の様子を見ながら使用し、発疹・発赤・かゆみなど肌に何らかの異常が生じた場合は、使用を中止し、専門医にご相談ください。

保守・点検のご注意

⚠ 警告



分解禁止

- 分解・改造・修理をしないでください。修理はご購入店舗または弊社カスタマーセンターにご相談ください。



禁止

- ACアダプターやプラグピンにほこりを付着させないでください。
(火災・感電・故障の原因)
- 落としたり、ぶつけたりしないでください。
- お子様の手が届く場所に保管したり、使用させないでください。
- 次のような場所に保管しないでください。
 - ・直射日光があたる場所・湿気が多い場所・粉塵が多い場所
 - ・高温または氷点下になる場所・炎天下の自動車内など
 - ・引火の危険がある場所・風雨にさらされる場所
 - ・化学薬品やガスが発生する場所・振動が激しい場所
 - ・暖房器具や熱が発生する器具の近く・磁石の近く



必ず守る

- お掃除の仕方
水分を含ませ、固く絞ったやわらかい布で拭き取ってください。硬い布で拭くと傷ついたり、機能が低下する原因となります。
※アルカリ剤・アルコール・シンナー・ベンジンなどの溶剤や除光液・磨き粉・熱湯・薬品類は使用しないでください。
※美容液が付着した状態で放置しないでください。

点検をしましょう

半年以上使用しなかった本機器を再度使用する際には、使用前に必ず異常がないかを点検してからご使用ください。(LEDの点灯状態・亀裂の有無等)
故障したままでご使用になりますと事故の原因となります。

各部の名称

本体




付属品

- ACアダプター
- USBケーブル(Type-C)
- 取扱説明書兼保証書

各部の名称

24KEp 素子採用



■ 肌との親和性が最も高いとされている、24金で表面加工を施しました。

※ とても柔らかい金属であるため、傷がつきやすくなっております。お取り扱いの際には十分にご注意ください。細かい擦り傷程度であれば、品質には問題ございませんので安心してご使用ください。

NFCタグ搭載モデル


■ NFC対応機器を本機器にかざすことにより、製品個々にシリアルNo.をご確認いただけます。

対応機種

■ iOS: iPhone XS/XR以降 ■ Android: 全般

※ iPhone 5S/5C ~ iPhone Xは対応アプリが必要です。
(App Store内にて「NFC読取」と検索してください)

※ NFC未対応機種ではご使用いただけません。



機能の説明

機能

| ボタン | モード | 機能 |
|-----|-----------|--|
| D | Dailyモード | CMP インサートパルス/EMS/中・高周波が同時に出力されます。 |
| | | EMP 筋肉を動かすことに特化したパルスが出力されます。 |
| W | Weeklyモード | TPとCMPが交互に出力されます。 TP(タッピングパルス)=CMPが断続的に出力されます。 CMP(カービング マルティプル パルス)=インサートパルス/EMS/中・高周波が同時に出力されます。 |

LED



- 赤色LEDの光でツヤのある弾力肌へと導きます。
- ※ 点灯中、光源を覗いたり直視をしないでください。
- ※ 目の周りのトリートメントの際は、目を閉じて使用してください。

充電方法

- 初めてご使用される際はフル充電をしてください。
 - 充電しながらの使用はできません。
- ※ 必ず電源をOFFにした状態で充電を開始してください。
- ① ACアダプターとUSBケーブルを接続します。
 - ② 本体の充電口のカバーをはずし、USBケーブルを差し込みます。
 - ③ コンセントにACアダプターを差し込みます。
- ※ 充電が開始すると、表示ランプが点灯します。

■ 表示ランプ(赤色)

| | |
|-----|-------|
| 充電中 | 充電完了時 |
| 点灯 | 消灯 |

操作方法

■ ご使用の前に、本機器が十分に充電されているか確認してください。


Dailyモード (CMP/EMP)

① モード選択

- Dボタンを長押しすることで、CMPが起動します。
- CMPの状態からDボタンを長押しすることで、EMPに切り替わります。

※ いずれもレベルは1段階のみです。

※ 起動から2分30秒後に音が鳴ります。



② 電源OFF

- EMPの状態からDボタンを長押しすることで電源をOFFにします。

※ 起動から5分後に自動停止します。(停止する5秒前より音が鳴ります。)

Weeklyモード

① モード選択

- Wボタンを長押しすることで、Weeklyモードが起動します。

※ レベル1の状態です。

※ 起動から2分30秒後に音が鳴ります。

② レベル選択

- レベルは3段階あります。Wボタンを押すことで、出力レベルを選択できます。

※ 初めて使用される際はレベル1から開始し、心地よいと感じるレベルでトリートメントを行ってください。

※ レベルを下げる際は、本体の電源をOFFにしてから再度設定を行ってください。



③ 電源OFF

- Wボタンを長押し、またはレベル3の状態ですら再度Wボタンを押すことで電源をOFFにします。

※ 起動から5分後に自動停止します。(停止する5秒前より音が鳴ります。)

トリートメント手順

トリートメント前

- ① ネックレス、指輪などのアクセサリーや、身につけているすべての貴金属類を外してください。
- ② 通常のクレンジングや洗顔により、化粧品や皮脂などの汚れを落とした上で、使用してください。

トリートメント

毎日のトリートメント

- Dailyモード CMP= 5分 EMP= 5分
 - CMP: 本体の素子部分全体に美容液を塗布し、トリートメントを行ってください。
 - EMP: トリートメント部位に美容液を塗布し、トリートメントを行ってください。
- ※ トリートメント手順について詳しくはp.12をご覧ください。

特別な週1回のトリートメント

- Weeklyモード = 5分
 - 本体の素子部分全体に美容液を塗布し、トリートメントを行ってください。
- ※ トリートメント手順について詳しくはp.12をご覧ください。


- トリートメントを行う部位へ4つの素子をすべて密着させてください。密着できていない場合、正しく出力されません。

トリートメント後


- ① トリートメント後、肌に残った美容液はやさしくなじませてください。
- ② トリートメントが終了したら、水分を含ませた柔らかい布やティッシュなどで本体の汚れを拭き取り、その後乾いたティッシュで水分を拭き取ってください。

トリートメント手順

- CMP/Weeklyモード:本体の素子部分全体に美容液を塗布し、イラストの位置で順番に肌にあててください。
- EMP:トリートメント部位に美容液を塗布し、イラストの位置で順番に肌にあててください。




目頭から目尻に向かって5箇所当てます。1箇所につき約3秒当て、5回繰り返します。



目頭から目尻に向かってゆっくりと5回動かします。



眉頭から眉尻に向かって5箇所当てます。1箇所につき約3秒当て、5回繰り返します。



眉頭から目尻に向かってゆっくりと5回動かします。

- ※ イラストのトリートメント手順は目安となります。
- ※ トリートメントの途中で乾きを感じたら、美容液を付け足してください。
塗布量が少なすぎると肌に刺激を感じたり、トリートメントの効果が発揮されない場合があります。
- ※ トリートメント部位へ素子をすべて密着させてください。
- ※ 使用中、ヘッドの表面に汚れなどが付着してざらつく場合は、柔らかい布やティッシュなどで拭き取ってください。
- ※ 体調が悪い場合には、使用しないでください。

⚠ 警告

粘膜や上まぶた、眼球や耳のまわり、のどぼとけ周辺には使用しないでください。

製品仕様

| | |
|-------------|--|
| 商品名 | CHOUOHC THE MORPHO CARVER (ザ・モルフォカーバー) |
| ACアダプター定格電源 | 入力 100-240V ~ 50/60Hz 出力 5V = 1.0A |
| 本体定格電源 | 入力 5V = 1.0A |
| 消費電力 | 最大4W |
| 外形寸法 | 本体+キャップ: 約H160 × W38.8 × D25.5mm |
| 質量 | 本体+キャップ: 約80g |

リチウムイオン電池のリサイクルについて

リチウムイオン電池はリサイクル可能な貴重な資源です。

本製品にはリチウムイオン電池が内蔵されているため、一般のゴミとして廃棄することができません。

本製品が不要になりましたら、分解せず宅配便等の配達記録が残る方法にて、弊社カスタマーセンターまでご送付ください。弊社が責任を持ってリサイクルいたします。



■ 送付時のご注意

- 配送料はお客様のご負担となります。着払いでご送付いただいてもお受け取りできません。
- 他社製品、および小型充電式電池に該当しないもの(乾電池・ボタン型電池など)は回収対象外です。
- 本体以外の同梱品(ACアダプターなど)は回収対象外です。
- 回収対象外品が混入していた場合はお受け取りできません。その際は、お客様のご負担にてご返送させていただきます。
- 回収品のお引き渡し(宅配業者が回収品を受領した時、または郵便物として集荷されたときを含みます)により、回収品の所有権は弊社に移転するものとします。また、回収品のお渡し後における回収中止、回収品の返却には応じられません。

保証規定

■ 保証書は取扱説明書の記載内容で、無償修理を行うことをお約束するものです。万が一、ご購入日から保証期間中に故障が発生した際は、本保証書のコピーを添付の上、ご購入店舗または弊社カスタマーセンターに修理をご依頼ください。

※ シリアル No.・ご購入店舗・ご購入日・お客様名・ご住所・お電話番号の記載がない場合、保証書は有効となりませんので、記入漏れの無い事を事前に必ずご確認ください。

※ 付属品(ACアダプター・USB ケーブル・取扱説明書兼保証書)は保証対象外となります。

※ 保証書のシリアル No. シールを剥がされた場合は、保証対象外となりますのでご注意ください。

■ 保証期間内でも次の場合は有償修理とさせていただきます。

- A. 保証書のシリアル No. シールを剥がされた場合
- B. 本保証書にシリアル No.・ご購入店舗・ご購入日・お客様名・ご住所・お電話番号の記載がない場合
- C. 使用者側での輸送・移動時等の落下・水没等によりお取り扱いが不適切なために生じた損傷や故障の場合
- D. 火災・天災・異常電圧により損傷・故障した場合
- E. 接続している他の機器に起因して、本製品が故障した場合
- F. 本製品付属の専用 AC アダプター以外を使用し故障した場合
- G. 弊社以外で修理・調整・改造をした場合
- H. 本保証書のご提示がない場合

■ この保証書は国内で使用される場合にのみ有効です。

※ 海外で購入された際は、製造メーカーより発行された正規代理店証明書がある場合のみ保証対象内です。

■ 送料について

- a. 保証期間内の送料は往復とも弊社負担とさせていただきます。(日本国内のみ有効)
- b. 保証期間外の送料は往復ともお客様負担とさせていただきます。

■ 本保証書は再発行いたしませんので、大切に保管してください。

TABLE OF CONTENTS

- INTRODUCTION _____ p. 16
- SAFETY PRECAUTIONS _____ p. 16~17
- PRECAUTIONS BEFORE USE _____ p. 18
- PRECAUTIONS IN USE _____ p. 19
- PRECAUTIONS OF MAINTENANCE
AND INSPECTION _____ p. 20
- NAME OF PARTS _____ p. 21~22
- FUNCTION DESCRIPTION _____ p. 23
- HOW TO CHARGE _____ p. 23
- HOW TO USE _____ p. 24
- TREATMENT PROCEDURE _____ p. 25~26
- PRODUCT SPECIFICATIONS _____ p. 27
- BATTERY RECYCLE _____ p. 27
- ASSURANCE PROVISION _____ p. 28
- MEMO _____ p. 44~46
- WARRANTY CARD _____ Back cover




INTRODUCTION

- Thank you for purchasing CHOUHC THE MORPHO CARVER. This instruction manual is for ensuring safe and proper use of this product. Please always include this Instruction manual when passing this product to another user.
- This instruction manual contains the warranty card. Confirm the information such as " The date of purchase" and " The store name or dealer name", and store it carefully.




SAFETY PRECAUTIONS

Be sure to read this instruction manual carefully before using, and always use properly.

To avoid the risk of injury, loss of life, and damage to any property, the following symbols are used. The marks and meanings of symbols are shown as below.

| | |
|--|---|
|  DANGER | DANGER indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury. |
|  WARNING | WARNING indicates a potentially hazardous situation which, if not avoided, may result in death or serious injury. |
|  CAUTION | CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor injury or property damage. ※Property damage means damage to house, household belongings, livestock or pets. |

■ MEANINGS OF SYMBOLS

| | |
|---|--|
|  | This symbol indicates prohibition. ※The detail content is written inside or near this symbol. |
|  | This symbol indicates compulsory actions |
|  | This symbol indicates attention is needed. |

SAFETY PRECAUTIONS

WARNING

To avoid accidents and discomfort.

■ Do not use this product with any of the following medical electrical equipment.



Prohibition

- Malfunction of medical electronic equipment causes accidents or discomfort.
- Implantable medical electrical equipment such as a pacemaker.
- Life support medical electrical equipment such as an artificial heart-lung device.
- Wearable medical electrical equipment such as an electrocardiograph or a dropper.

■ The following persons must not use the product.



Prohibition

- Persons with heart disease, abnormal blood pressure or malignant tumors.
- Persons with diseases with fever, infectious diseases or acute diseases.
- Persons who are receiving dental treatment.
- Persons with weakened immune systems or who use immune suppressants due to immunity disorders like AIDS etc.
- Persons with hemophilia, bleeding disorders, diabetes or facial neuralgia.
- Persons with paresthesia or dysalgesia.
- Persons with Keloid diathesis, facial melanosis, photosensitivity or pigmentation disorders.
- Persons with capillary dilatation due to long-term steroidal hormone treatments or liver dysfunction.
- Persons who have allergies, atopic dermatitis, skin diseases, sensitive skin or weak skin.
- Persons who have epileptic stroke or discomfort due to flashing lights.
- Persons who have aftereffects of head or ophthalmologic aftereffects due to traffic accidents.
- Persons who have had eye operations (in the case of LASIK, consult with the doctor before use).
- Persons who are pregnant, on period or breast-feeding.
- Children or the person who cannot express their feelings in words.
- Persons under the influence of alcohol or with a hangover.
- Persons who take drugs that cause drowsiness.
- Persons who are extremely tired or do not feel well.
- Persons who have had skin problems such as spots or rashes due to artificial fibers.
- Persons who have or have had skin-inflammation due to cosmetics.
- Persons immediately after having chemical peeling at beauty salons etc.
- Persons who have had skin problems after using beauty equipment.

■ Do not use on the following parts.



Prohibition

- Except specific parts.
- Around heart, eyeballs, upper eyelids, lips, and mucous membrane such as inside the mouth.
- Private parts, anus, around the Adam's apple and ears.
- Parts with morbid spots, moles, and viral warts.
- Tinged and inflamed parts due to excessive sunburn.
- Parts with wounds, eczema, psoriasis, herpes, purulent acnes and/or pimples.
- Parts with pathological spots due to itching, flushing, physical stimulus.
- Parts where surgery was performed.
- Any parts immediately after hair removal or shaving has been performed.

※ If you are seeing a doctor, consult with the doctor before use.

PRECAUTIONS BEFORE USE

WARNING

- Do not use this product with other beauty equipment at the same time.
- Do not use this product for any purpose other than beauty and under conditions of malfunction or damage. This product is a treatment equipment specialized for use in beauty. Do not use for other purposes such as therapeutic purposes.
- Do not look at or directly view the LED light.
- Do not use continuously on the same parts.
Problems or symptoms such as skin damage, infection, inflammation, bleeding, pigmentation may be aggravated.
- Do not use serums that contain alcohol ingredients. It may cause skin problems.
- Do not use on pets.
- Do not use near flammable substances such as thinner, benzene, polish removers or sprays.
- Do not use with anything other than the dedicated adapter and USB cord. Do not connect the dedicated adapter and USB cord to other equipment. "The cause of conflagration, electrification, or breakdown."
- Do not damage the USB cord.
- ※ Do not damage, bend more than necessary, pull, twist, place heavy objects on top of, interpose. "Causes of fire, electric shock or damage."
- Do not adopt a star-burst connection. "Causes heat generation or fire."



Prohibition



Prohibition of use in a wet area



Prohibition of getting wet



Prohibition of use with wet hands



Unplug



Compulsion

- Do not use and keep in the bathroom or high humidity places.
- Do not leave in places where water is easily splashed "on a sink etc.".
- Do not immerse in water, pour or spill water (the causes of electric shock, fire or damage).
- Do not touch with wet hands. (the causes of electric shock or injury)
- Make sure to hold the end of the plug when putting in or pulling the adapter. Do not grab the cord to put in or pull the adapter.
- Do not use when the adapter is damaged or the insertion to any outlet is loose.
- Make sure to use only household outlets.
- Insert firmly up to the root of the adapter and the plug.
- Make sure to observe the instruction manual. If you don't observe, it may cause any problem.

PRECAUTIONS IN USE

WARNING



Unplug

- Stop using the product, turn off the power, and pull the adapter from the outlet in the following cases.
 - Earthquakes or lightning.
 - Smoke, abnormal heat, odor or distortion of the main body, the adapter or the cord.



Prohibition

- During use, this product may slightly heat up but this is not a safety issue.
- Do not bring this product into contact with metals and any other electric appliances such as mobile phone, television.
- Charge completely before first time use this product.
- ※The product turns the power off if it is not charged enough.



Compulsion

- Make sure to remove all metal objects, glasses and contact lenses during use.
- ※Metal objects: Pierced earrings, necklaces, watches etc.
- Make sure to set to level 1 when using for the first time or until you get used to it.
- Do not press the head of product to the skin strongly and never place on the same part of the skin for longer than 3 seconds. This may cause skin troubles.
- During treatments around eyes, use this product with your eyes closed.
- Discontinue use immediately if abnormalities appear on the skin or in the body during use and consult with a doctor.

CAUTION

Precautions of the use of product.

Read the following sections carefully before use.

1

- Perform a special treatment once a week.
 - Perform a treatment twice a week in the first and second weeks. From the third week, perform a treatment about once a week on your skin conditions.
 - Excessive treatment is not good for the skin.
- Give daily treatments every day or every other day.
 - Use this product according to your skin conditions.

2

- As to Treatments, remove makeup and wash your face to remove impurities such as makeup cosmetics and sebum on your skin and apply the dedicated beauty essence, then use this product.

3

- Skin conditions are different depending on your physical conditions.
 - Use this product while observing your skin conditions, and discontinue use if abnormalities such as rashes, redness or itchiness appear on skin and consult with dermatologist.

PRECAUTIONS OF MAINTENANCE AND INSPECTION

WARNING



Prohibition of disassembly

- Do not disassemble, modify, or try to repair the device yourself. For repair, please inquire at dealer.



Prohibition

- Do not adhere dust and pin on AC adapter and plug. (Cause fire, electric shock or damage).
- Do not drop or hit this product.
- Do not wrap the code around the adapter when storing the device.
- Please keep out of reach of children and do not let them use this product.
- Do not store this product in the following places.
 - Places subject to direct sunlight, high humidity and dust.
 - Places subject to high temperature or temperature below freezing point or inside a car under the blazing sun.
 - Places subject to danger of ignition, rain or wind.
 - Places subject to chemicals, gas generation or excessive vibration.
 - Places being close to heating appliances, appliances generating heat and magnetic sources.



Compulsion

- How to clean
 - Wipe this product using a soft cloth dampened with water. If wiping with a hard cloth, the product may be damaged or this may cause deterioration in performance.
 - ※ Do not use solvents such as alkaline agents, alcohol, thinner or benzene, polish removers, polishing powders, hot water or chemicals.
 - ※ Do not leave this product with the beauty essence on it after use.

INSPECTION

When this product is unused for longer than 6 months and is used again, make sure to inspect before use if there are any abnormalities (the lighting state of the LED lights and the presence of absence of cracks).

If used under faulty conditions, this may cause an accident.

NAME OF PARTS

Main Body




Accessories

- AC adapter
- USB cable (Type-C)
- Instruction manual with warranty card

NAME OF PARTS

24KEp elements



- The surface processing is applied using 24-karat gold that is said to have the highest affinity to the skin.
- ※ This metal is really soft and easily scratched. Please handle it with sufficient care. If there are any small scratches, it will not any problem with quality of the device. It is safe to use.


Model equipped with NFC Tag

- It is possible to confirm Serial No. by holding NFC-compatible device up to this product.

Compatible models

- iOS : iPhone XS/XR or newer
- Android : all

- ※ iPhone older than iPhone X requires a compatible app. (Search for "NFC Reader" in the App store)
- ※ Not available with NFC-incompatible models.



FUNCTION DESCRIPTION

Function

| Button | Mode | | Function |
|--------|-------------|-----|--|
| D | Daily mode | CMP | Output insert pulse,EMS and mid-high frequency at the same time. |
| | | EMP | Output a pulse specialized in working muscles. |
| W | Weekly mode | | Output alternately TP and CMP. TP (Tapping Pulse) outputs CMP intermittently. CMP (Carving Multiple Pulse) outputs insert pulse,EMS and mid-high frequency at the same time. |

LED



- Red LED leads to elastic and lustrous skin.
- ※ Do not look directly at the LED light.
- ※ Keep eyes closed during treatment around eyes.

HOW TO CHARGE

- Please fully charge the device when first use.
- The product can't be used while charging.
- ※ Please charge the product when the power is turned off.
- ① Connect the AC adapter with USB code.
- ② Remove the cover of charging port, and insert USB cable into it.
- ③ Plug the AC adapter into a power outlet.
- ※ The indicator lamp will light up when the battery starts charging.

■ Indicator lamp (Red)

| | |
|-------------|---------------|
| Charging | Fully charged |
| Lighting up | Lights-out |


HOW TO USE

- Make sure the battery is fully charged before use.

Daily mode (CMP/EMP)

1 Mode

- CMP starts by holding D button down.
- Switch from CMP to EMP by holding D button down.
- ※ EMP and CMP is level 1.
- ※ The device makes sound 2 minutes and 30 seconds after startup.



2 Turn off the power

- Turn off the power by holding D button down in the state of using EMP.
- ※ The device stops automatically in 5 minutes after starting up. (The sound can be heard once every second from before around 5 seconds of a stop.)

Weekly mode

1 Mode

- Weekly mode starts by holding W button down.
- ※ Each mode starts with level 1.
- ※ The device makes sound 2 minutes and 30 seconds after startup.

2 Level

- There are 3 levels. Select the level by pressing W button.
- ※ Make sure to set to level 1 when using for the first time or until you have got used to it.
- ※ When lowering the level, turn the power off and then reset the level.



3 Turn off the power

- Turn off the power by holding W button down or press W button in the state of using Weekly mode with level 3.
- ※ The device stops automatically in 5 minutes after starting up. (The sound can be heard once every second from before around 5 seconds of a stop.)

TREATMENT PROCEDURE

Before treatment

- 1 Remove accessories such as necklaces or rings and all metal objects that you are wearing.
- 2 Before performing a treatment, remove makeup and wash your face to remove impurities such as makeup cosmetics and sebum on your skin.

While performing a treatment

Daily treatment

- Daily mode CMP = 5 minutes EMP = 5 minutes
 - CMP: Apply the beauty essence on the element parts of this product and then perform treatment.
 - EMP: Apply the beauty essence on the treatment parts and then perform treatment.
- ※ Please read the treatment procedure on the page 26.

Special treatment once a week

- Weekly mode = 5 minutes
 - Apply the beauty essence on the element parts of this product and then perform treatment.
- ※ Please read the treatment procedure on the page 26.


■ Please adhere closely all 4 elements on skin while treatments. If not, it doesn't output correctly.

After treatment


- 1 After treatment, spread the beauty essence.
- 2 After treatment, wipe away the product with a soft cloth or tissues.

TREATMENT PROCEDURE

- **CMP/Weekly mode:** Apply the beauty essence on the element parts, and then perform the treatment.
- **EMP:** Apply the beauty essence on the treatment part, and then perform the treatment.



Place this product to 5 points in the illustration for approx. 3 seconds and repeat it 5 times.



Move from the inner corner of the eye to the temple and repeat it 5 times.



Place this product to 5 points of brow bone in the illustration for approx. 3 seconds and repeat it 5 times.



Move from the inner eyebrow to the end of eyebrow 5 times.

- ※ The treatment procedure in the illustration is an indication.
- ※ During the treatment, apply more the beauty essence if the treatment area becomes dry.
When the treatment area becomes dry, it may cause irritation on skin and the reduction of its effect.
- ※ Please adhere closely all elements on skin while treatments.
- ※ During use, in the case that the surface of the product's head becomes rough by the adhesion of dirt etc., wipe the surface of the head using a soft cloth.
- ※ Do not use the product when you do not feel well.

WARNING

Do not use on mucosa, upper eyelids, eyeballs, ears, and Adam's apple.

PRODUCT SPECIFICATIONS

| | |
|----------------------------|--|
| Product name | CHOUOHC THE MORPHO CARVER |
| Power rating of AC adapter | Input 100-240V ~ 50/60Hz Output 5V = 1.0A |
| Power rating of Main body | Input 5V = 1.0A |
| Power consumption | Maximum 4W |
| Size | Main body+Cover : Approx. H160×W38.8×D25.5mm |
| Weight | Main body+Cover : Approx. 80g |

BATTERY RECYCLE

Ensure to take out the lithium ion battery when disposing the device. Before take off the battery, make sure to consume the power of the battery completely.

Do not discard the the lithium ion battery. Please follow your local government rules to dispose in the specified battery recycling place.

(Battery removal procedure:Unclench the shell of the device with a tool, then take out the battery. Be careful to avoid the the battery's positive and negative short-circuiting.)



Li-ion

ASSURANCE PROVISION

■ This warranty promises free repair subject to the content written in the instruction manual. If the product is damaged within the warranty period from the date of purchase, please contact the purchase store or our customer center by submitting a copy of this warranty.

※ In the case that the serial number, date of purchase, name of dealer, customer name, address and phone number are not filled out on the warranty card, the warranty is not valid so please make sure to check that you have not missed out any required information in advance.

※ Accessories (AC adapter, USB cable, instruction manual with warranty) are not covered by the warranty.

※ In case the serial No. stickers on the main body and the warranty card are removed, the product is not covered by the warranty.

■ **There will be a charge for repairing in the following cases even within the warranty period.**

A. In the case of the removal of the serial No. stickers from the warranty card.

B. In the case that the serial No., the date of purchase, dealer name, customer name, address, and phone number are not filled out on the warranty card.

C. Malfunction or damage due to improper handling (e.g. dropping and submerging in water) caused during transportation or moving by the user.

D. Malfunction or damage due to fire, other natural disasters or abnormal voltage.

E. Damage due to other devices connected to this product.

F. Damage due to the use of an AC adapter other than the dedicated AC adapter included with this product.

G. In the case of repair, adjustment or modification by anyone other than us.

H. In the case of not submitting of the warranty card.

■ **This warranty card is valid only in Japan.**

※ In the case of purchasing this product overseas, the warranty covers the product only when the store or dealer where user purchased the product has an authorized distributor certificate issued by manufacturer.

■ **Shipping fee**

a. The shipping fee for the return and redelivery shall be borne by our company within the warranty period. "Valid in only Japan"

b. The shipping fee for the return and redelivery shall be borne by the customer outside the warranty period.

■ **This warranty card is not reissued. Please keep it carefully.**

目录

- 使用说明书相关注意事项 _____ p. 30
- 为了正确安全地使用本仪器 _____ p. 30~31
- 使用前的注意事项 _____ p. 32
- 使用时的注意事项 _____ p. 33
- 维护·检查的注意事项 _____ p. 34
- 各部件的名称 _____ p. 35~36
- 功能说明 _____ p. 37
- 充电方法 _____ p. 37
- 本仪器操作方法 _____ p. 38
- 护理顺序 _____ p. 39~40
- 产品规格 _____ p. 41
- 电池的回收处理 _____ p. 41
- 有毒有害物质含量表 _____ p. 42
- 保修规定 _____ p. 43
- MEMO _____ p. 44~46
- 保修书 _____ 封底


使用说明书相关注意事项


- 非常感谢您购买本公司的商品。
为了安全使用本仪器，必须遵守使用说明书。将本仪器借给他人或赠与他人时，请务必将本使用说明书一起交给对方。
- 本使用说明书附有保修书。
请务必确认已填写「购买日、购买店铺名」等，并妥善保管。


为了正确安全地使用本仪器

使用前请务必仔细阅读本说明书，并正确使用。

为了防止对您或他人造成人身危害或财产损失，现使用如下图示来表示危害和损失的程度，请理解内容之后再阅读正文。警告标识的标志和意思如下。

 **危险** 极有可能造成人员死亡或重伤的内容。

 **警告** 可能造成人员死亡或重伤的内容。

 **注意** 可能会造成人员轻伤或财产损失※的内容。
※表示对房屋、家具以及家畜、宠物造成的扩大损失。

■ 图标



表示不能做的「禁止」内容。
※图中或旁边标有具体内容。




表示必须遵守的内容。



表示必须注意的内容。

为了正确安全地使用本仪器

 **警告：如果不遵循使用说明，可能导致不良影响。**



禁止

■警告：使用下述医用电子仪器的人，请勿使用本仪器。

否则可能因医用电子仪器的错误运行导致事故或身体不适。

- 起搏器等人体植入式医用电子仪器
- 人工心肺机等用于维持生命的电子仪器
- 心电图仪、输液器等佩戴型医用电子仪器

■如果您符合下列情况，请勿使用。

- 患有心脏病、血压异常、恶性肿瘤
- 伴有发烧症状、或患有感染性疾病、急性病
- 牙齿治疗期间
- 因艾滋病等免疫缺陷病而造成免疫力下降，或正在使用免疫抑制剂
- 患有血友病、出血性疾病、糖尿病、面部神经痛
- 知觉、痛觉异常
- 瘢痕疙瘩体质、患有脸部黑皮病、光过敏症、色素异常症
- 长期使用类固醇激素类药物或因肝功能障碍而引发毛细血管扩张
- 过敏体质、过敏性皮炎、皮肤病、敏感肌或肌肤脆弱
- 曾有癫痫病史或会因光线闪烁而感到不适
- 因交通事故等造成头部或眼部后遗症
- 曾接受过眼部手术（如接受过激光原位角膜磨镶术，请咨询医生后再使用）
- 孕妇、正处于生理期、哺乳期
- 幼儿、无法表达自己意思的人
- 醉酒、宿醉
- 正在服用助眠药物
- 极度疲劳、身体不适
- 曾因化学纤维而引发色斑、接触性皮炎等肌肤问题
- 会因化妆品而引发或曾经引发过皮炎
- 近期在护肤沙龙等接受过化学换肤疗程
- 使用美容仪器后曾出现肌肤问题



禁止

■请勿用于以下部位。

- 非指定部位
- 心脏周围、眼球及上眼睑、嘴唇和口中等处的黏膜部位
- 阴部、肛门、喉结周围、耳朵
- 病态色斑、痣或病毒性疣的部位
- 因过度日晒而引发肌肤刺痛、炎症的部位
- 有伤口、湿疹、干癣、疱疹、化脓的痤疮和青春痘的部位
- 发痒、发热、物理性刺激等引发病理性色斑的部位
- 曾接受手术的部位
- 近期接受过脱毛或剃毛处理的部位



禁止

※如果您正在接受医院治疗，请在使用前咨询您的医生。

使用前的注意事项

⚠ 警告: 如果不遵循使用说明, 可能导致不良影响。



禁止

- 警告: 请勿和其他美容仪同时使用。
- 警告: 请勿用于非美容目的。请勿在损坏、故障的状态下使用。
本美容仪为美容专用护理仪, 请勿用于治疗目的或其他用途。
- 警告: 请勿窥视或直视LED光。
- 警告: 延长或重复在一个表面部位使用本器具可能导致对皮肤潜在的损害。
- 警告: 请勿连续用于同一部位。否则可能会伤害肌肤或造成感染、炎症、出血、色素沉淀等肌肤问题或导致症状恶化。
- 警告: 请勿搭配含有酒精成分的化妆品使用。如果含酒精, 等酒精完全挥发之后, 才开始使用电皮肤刺激器进行护理。
- 警告: 请勿使用在宠物身上。
- 警告: 请勿搭配含有易燃成分的化妆品使用。或在稀释液、挥发油、去光水、喷雾等易燃品附近使用。
- 警告: 请勿使用非专用AC适配器、USB连接线。请勿将专用AC适配器、USB连接线连接其他仪器。
否则会导致火灾、触电或故障。
- 警告: 请勿损坏USB连接线。
- ※ 请勿毁伤、强行弯曲、拉扯、扭曲、在上面放置重物、紧夹等。否则会导致火灾、触电或故障。
- 警告: 请勿使插座过载。
否则会导致发热或火灾。



禁止在潮湿处使用

- 请勿在浴室或湿气多的地方使用或保管。
- 请勿放置在容易碰到水(洗脸台上等)的地方。



禁止浸水

- 请勿将本仪器浸在水中, 或是将水淋到或洒到本仪器上。
否则会导致触电、火灾或故障。



禁止湿手使用

- 请勿以湿手触碰仪器。
否则会导致触电、受伤。



拔出插头

- 插拔AC适配器时, 请务必手持前端插头进行插拔。请勿手持线缆插拔。
- 如AC适配器损坏, 或插在插座后出现松脱时, 请勿使用。



必须遵守

- 仅适用于家用插座。
- 请确保插紧AC适配器及USB连接线。
- 请务必遵守使用说明书的内容。如果不遵守使用的话, 可能导致不良影响。

使用时的注意事项

⚠ 警告：如果不遵循使用说明，可能导致不良影响。



拔出插头

- 如出现下述情况，请停止使用并关闭电源，将AC适配器从插座上拔除。
 - 地震、打雷。
 - 本仪器或AC适配器、USB连接线冒烟、异常发热、发出异臭、变形。



禁止

- 使用时，本仪器可能会发热，不会产生安全上的问题。
- 请勿将本仪器连接到金属或电器产品。
 - ※手机、电视等。
- 第一次使用时，请务必充满电。
- ※若在充电不足的情况下使用，可能出现使用过程中断电的情况。



必须遵守

- 使用时，请务必摘下贵金属类、眼镜和隐形眼镜。
 - ※贵金属类：耳环、项链、表等。
- 第一次使用或尚未适应时，请务必从1档开始尝试。
- 请勿将护理头用力按压在肌肤上。请勿连续停留在同一部位超过3秒钟。否则会导致肌肤问题。
- 护理眼周肌肤时，请闭上双眼后再使用。
- 使用时如感到肌肤或身体疼痛、异常时，请立即停止使用并咨询医生。
- 在启动电皮肤刺激器之前先使电极与皮肤接触。
- 本仪器强度档位切换时，请务必注意电极电流密度的变化。
- 先断开电皮肤刺激器，然后再把电极与皮肤分开。

⚠ 注意

本仪器使用注意事项 请仔细阅读以下项目后再使用。

1

- 每周1次的特别护理：每周护理1次
 - 第1~2周 每周护理2次。之后的第3周开始视肌肤状态而定，约每周护理1次。
 - 过度护理反而不益于肌肤健康。
- 每天的日常护理：每天或2天一次
 - 请视肌肤状态使用。


2

- 请在卸妆，洁面后，肌肤洁净的状态进行护理。

3

- 肌肤状态因身体状态而异。
 - 使用时请视肌肤状态而定，若肌肤出现皮疹、发红、瘙痒等异常状况，请停止使用，并咨询专科医生。

维护·检查的注意事项

 **警告:**如果不遵循使用说明,可能导致不良影响。



禁止拆卸

- **警告:**不要旁路或取消器具固有的安全装置。请勿自行拆卸、改造或修理本仪器。需要修理时请咨询购买店铺或本公司售后服务中心。



禁止

- 请勿让AC适配器或插头吸附金属别针或沾到灰尘。否则会导致火灾、触电或故障。
- 请勿摔落或撞击本仪器。
- 收纳时,请勿将线缆缠卷在适配器上。
- 请勿保管在儿童能触摸到的地方或是让儿童使用。
- 请勿保管在下述地方。
 - 阳光直射的地方、潮湿的地方、粉尘多的地方
 - 高温或零度以下的地方、烈日下的汽车内等地方
 - 易燃的地方、风吹雨打的地方
 - 有化学药品或产生煤气的地方、振动强烈的地方
 - 供热器具和发热器具的附近、磁石的附近



必须遵守

- **清洁方法**
请用浸过水并拧干的软布擦去本仪器的污垢。用硬布擦拭会损伤本仪器,导致功能降低。
- ※请勿使用碱剂、酒精、稀释液、挥发油等溶剂或卸甲水、研磨粉、热水、药品类。
- ※本仪器上如沾有美容液,请于清洁后,再行保管。

长期未用,请检查!

如半年以上未使用本仪器时,使用前请务必检查并确保无异常后再使用。
(LED的亮灯状态、有无裂缝等)
若在故障状态下使用,会导致事故。

各部件的名称

本体



※图片仅供参考,请以实际产品为准。

配件

- AC适配器
- USB连接线 (Type-C)
- 使用说明书兼保修书

各部件的名称

采用镀金导头



- 表面采用与肌肤亲和度较高的镀金加工。
- ※ 由于金属质地非常柔软，容易产生划痕。使用时请注意。如出现细小的擦伤，并不影响品质，请放心使用。

搭载 NFC 标签机型


- 可以将支持 NFC 功能的设备贴近本仪器以查询产品序列号。

对应機種

- iOS: iPhone XS/XR 之后
- Android: 全機種

※ iPhone 5S/5C ~ iPhone X 需相应 APP。(请在 App Store 里搜索「NFC 读取」)

※ 不支持 NFC 功能的设备将无法对本仪器进行查验。



功能说明

功能

| 按键 | 模式 | | 功能 |
|----|----------|-----------------|----------------------|
| D | Daily模式 | CMP (精雕综合脉冲) | 同时输出导入脉冲/EMS/中高频波。 |
| | | EMP (眼周肌脉冲) | 输出具有活动肌肉作用的特殊脉冲。 |
| W | Weekly模式 | | 间歇性输出超脉冲电穿孔与CMP交替输出。 |

LED



■ 红色的LED灯可打造光泽和弹性肌肤。

※ 亮灯时，请勿窥视或直视光源。

※ 护理眼周围部位时，请闭上双眼。

充电方法

- 初次使用时，请将电充满。
 - 本仪器充电时不能使用。
- ※ 请务必在仪器电源关闭的状态下进行充电。
- ① 连接AC适配器和USB连接线。
 - ② 打开充电口防尘盖，插入USB连接线。
 - ③ 将AC适配器插入电源插座。
- ※ 充电开始时，显示灯亮起。

■ 显示灯(红色)

| 充电中 | 充电结束 |
|-----|------|
| 常亮 | 灯灭 |

本仪器操作方法

■ 使用前,请确认本仪器是否正常启动。


Daily 模式 (CMP/EMP)

① 模式选择

- 长按D按键,启动CMP模式。
- 在CMP模式的状态长按D按键,切换为EMP模式。

※ 两种模式均只有一个强度档位。

※ 各模式启动2分30秒钟后,发出提示音。



② 关闭电源

- 在EMP模式状态下,长按D按键即可关闭电源。

※ 各模式启动5分钟后,该模式自动停止。(停止运作约5秒钟前发出提示音。)

Weekly 模式

① 模式选择

- 长按W按键,启动Weekly周护理模式。

※ 开启时,是该模式的1档状态。

※ 模式启动2分30秒钟后,发出提示音。

② 强度档位选择

- 强度分为3档。按W按键,进行强度选择。

※ 初次使用时,请从强度1档开始尝试,然后调至较舒适的档位进行护理。

※ 想要降低档位时,请长按正在使用的模式按键,切断电源后,再重新启动,并进行档位选择。



③ 关闭电源

- 长按W按键,或者在强度3的状态下再次按W按键,电源关闭。

※ 模式启动5分钟后,该模式自动停止。(停止运作约5秒钟前发出提示音。)

护理顺序

护理前

- ① 请摘下项链、戒指等饰品，以及身上佩戴的所有贵金属类。
- ② 请和平时一样进行卸妆和洁面，洗去化妆品及皮脂污垢等后，再进行护理。

护理中

每天的日常护理

- Daily 模式 CMP = 5分钟 EMP = 5分钟
 - CMP 模式：将美容液涂抹于仪器导头后，进行护理。
 - EMP 模式：将美容液涂抹在护理部位后，进行护理。
- ※ 详细的护理操作，请参考 p.40。

每周1次的特别护理

- Weekly 模式 = 5分钟
 - 将美容液涂抹于仪器导头后，进行护理。
- ※ 详细的护理操作，请参考 p.40。

- 护理时请将4个导头全部贴合于面部。如果导头没有完全贴合肌肤，仪器将无法正常输出。

护理后

- ① 护理后，请将面部残留的美容液轻轻按摩吸收。
- ② 护理结束后，请以浸过水并拧干的软布或纸巾等擦拭本仪器，清除脏污后再以干纸巾拭除残留水分。


护理顺序

■ CMP模式/Weekly模式：将美容液涂抹于仪器导头后，按照下方图示顺序及方法，进行护理。


■ EMP模式：将美容液涂抹于护理部位后，按照下方图示顺序及方法，进行护理。

●：图示1, 3中，点压●的点位，各部位每次3秒钟以内。

→：图示2, 4中，按箭头指示方向缓慢滑动，重复5次。




点压眼睛下方五个点位，每次3秒钟以内，重复五次。



沿着点压路径从内眼角下方滑动至太阳穴，重复五次。



点压眼睛上方眉骨位置五个点位，每次3秒钟以内，重复五次。



沿着点压路径从眉头滑动至太阳穴，重复五次。

※ 图示为建议护理顺序。

※ 在护理过程中，如感觉肌肤干燥，请增加美容液用量。用量过少可能影响肌肤质感，同时护理效果也会有所减弱。

※ 护理时，请将导头完全贴合肌肤。

※ 使用过程中，如果发现护理头沾有污垢而凹凸不平时，请用软布或纸巾等擦拭干净。

※ 身体不适时，请勿使用。

⚠ 警告

请勿在黏膜、眼球及上眼睑、耳周以及喉结周围使用。

产品规格

| | |
|------------|---|
| 产品名称 | 闪蝶雕刻大师 |
| 产品型号 | THE MORPHO CARVER |
| AC 适配器额定电源 | 输入 100-240V~ 50/60Hz 0.4A 输出 5.0V = 1.0A |
| 电极最大输出 | 34mA |
| 导头面积 | 1.44cm ² |
| 外形 | 仪器本体+仪器盖:约160 × 38.8 × 25.5mm |
| 重量 | 仪器本体+仪器盖:约80g |

电池的回收处理

本仪器报废处理时,必须将锂电池内电量消耗并从本仪器中取出。
在取锂电池时,仪器必须断电。

根据中华人民共和国法律法规,锂电池不得随意丢弃,请按规定放置在指定的电池回收场所。

(电池拆卸方法:用工具撬开美容仪外壳,拔出电池,即可取出。请勿让电源正负极接触发生短路。)



有毒有害物质含量表

本表格依据SJ/T11364-2014的规定编制。

| 部件名称 | 有毒有害物质或元素 | | | | | |
|--------|-----------|---------|---------|-------------|-------------|---------------|
| | 铅 Pb | 汞 Hg | 镉 Cd | 六价铬 CrVI | 多溴联苯 PBB | 多溴苯二醚 PBDE |
| 壳料,结构件 | ○ | ○ | ○ | ○ | ○ | ○ |
| PCB电路板 | × | ○ | ○ | ○ | ○ | ○ |
| 线材 | × | ○ | ○ | ○ | ○ | ○ |
| 金属零件 | × | ○ | ○ | ○ | ○ | ○ |
| 塑料零件 | ○ | ○ | ○ | ○ | ○ | ○ |

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T26572-2011规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572-2011规定的限量要求。现阶段暂无可以替代的技术和部件，但符合国家相关法规的要求，同时我司会继续努力通过改进技术来减少有害元素的使用。



保修规定

■ 按保修书记录内容，依据保修规定，提供保修期内免费维修服务。自购买日起，在保修期内发生故障，请附上本保修书的复印件，委托购买店铺或本公司售后服务中心进行修理。

※ 如没有填写序列号、购买日、购买店铺名、顾客姓名、地址、电话号码，本保修书将视作无效，请务必事先确认没有漏写。

※ 配件（AC 适配器、USB 连接线、使用说明书兼保修书）不适用于保修。

※ 另外请注意，保修书的序列号贴纸剥落时，不适用于保修。

■ 即使在保修期内，若属下列情况，无法提供免费维修。

A. 保修书的序列号贴纸剥落

B. 本保修书上没有填写序列号、购买日、购买店铺名、顾客姓名、住址、电话号码

C. 运输、移动时发生摔落、水淹等因使用者的不当处理而引起的故障及损伤

D. 火灾、天灾、异常电压而引起的损伤及故障

E. 因连接其他仪器而引起的本仪器故障

F. 使用非本仪器附属专用 AC 适配器而引起的故障

G. 非本公司进行的修理、调整、改造

H. 没有出示本保修书

■ 此保修书仅限于国内使用时有效。

※ 如在海外购买，仅限持有制造商发行的正规代理店证明方可适用于保修。

■ 关于邮费

a 保修期间内往返邮费由我司负担。（仅限日本国内有效）

b 保修期间外往返邮费由顾客负担。

■ 本保证书遗失不补，请妥善保管。

保証書 / WARRANTY CARD / 保修书

※修理の際は必ずコピーを1部添えてください。

| | | | |
|---------|--|---|---|
| 商品名 | CHOUOHC THE MORPHO CARVER (ザ・モルフォカーバー) | | |
| シリアルNo. | [] | | |
| 保証期間 | ご購入日から 本体のみ1年間 (その他付属品は対象外) | | |
| ご購入店舗 | | | |
| ご購入日 | 年 | 月 | 日 |
| お客様名 | | | |
| ご住所 | 〒 | — | |
| お電話番号 | (|) | — |

ご不明な点がございましたら、お気軽にご相談ください。

- 使い方がよく分からない
- 部品が破損し、部品を取り替えたい
- 本体が動かない
- 消耗品を購入したい
- 本体を修理したい
- 等

カスタマーセンター

株式会社 **CHOUCHOU**

☎ **043-227-8885**

受付時間:10:00~17:00 (土日祝日を除く)

■本保証書は取扱説明書の記載内容で、無償修理を行うことをお約束するものです。万が一、ご購入日から上記期間中に故障が発生した際は、本保証書のコピーを添付の上ご購入店舗または弊社カスタマーセンターに修理をご依頼ください。

※シリアルNo.・ご購入店舗・ご購入日・お客様名・ご住所・お電話番号の記載がない場合、保証書は有効となりませんので、記入漏れの無い事を事前に必ずご確認ください。

※保証書のシリアルNo.シールを剥がされた場合は、保証対象外となりますのでご注意ください。

※保証書によって、お客様の法律上の権利を制限するものではありません。

販売元 株式会社 **CHOUCHOU**

〒263-0003 千葉県千葉市稲毛区小深町108-1

TEL:043-227-8885